

Sport-Thieme Licherhimmel

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben!

Damit Sie viel Freude an diesem Produkt haben und die Sicherheit gewährleistet ist, sollten Sie diese Anleitung vor dem Gebrauch zunächst vollständig durchlesen. Bewahren Sie die Anleitung gut auf. Für Fragen und Wünsche stehen wir Ihnen gerne zur Verfügung.



Warnung

- Für den Innenraumgebrauch nur sichere Niedrigvolt-Transformer benutzen!! Diese dürfen nicht dem Wetter ausgesetzt werden.
- Bitte lesen Sie diese Anweisungen und behalten Sie sie zum Nachlesen, um die sichere und zufriedenstellende Nutzung des Lichter-Sets zu garantieren.

Sicherheitshinweise

- Lösen Sie das Set von der Box, bevor Sie die Verbindung zur Steckdose herstellen.
- Gebrauch nur mit dem mitgelieferten Transformer. Das Lichterset ist auch sicher für den Außengebrauch, der Transformer muss allerdings im Innenbereich bleiben oder überdacht sein.
- Bei Nichtgebrauch von der Hauptleitung nehmen.
- Setzen Sie das Set keiner direkten Hitze oder Flammen aus und tauchen Sie es nicht in Wasser. Die Glühbirnen dürfen nicht in Kontakt mit zerbrechlichen oder schmelzenden Materialien kommen.
- Behandeln Sie die Kabel, Controller (falls im Leistungsumfang enthalten) und Glühbirnen sorgfältig, um Schäden zu vermeiden.
- Verbinden Sie dieses Set nicht elektrisch mit anderen Sets.
- Kein Gebrauch, wenn das Kabel abgeschnitten, ausgefranst oder beschädigt ist oder wenn Kabel ohne Isolierung sind.
- Achten Sie darauf, dass das Kabel nicht beschädigt wird, wenn es in einem Türeingang oder Fensterahmen liegt, insbesondere, wenn diese aus Metall bestehen.
- LED Glühbirnen können nicht ersetzt werden. Versuchen Sie nicht, sie zu entfernen.

Kontroller Aufgaben

1. Verbindung
2. In Wellen
3. Aufeinanderfolgend
4. Slo-Glo
5. Chasing/Aufleuchten
6. Dimmen
7. Funkeln/Aufleuchten
8. Langsam

Fehlerbehebung

Wenn die Lichter nicht gehen:

Gehen Sie sicher,

- dass die Lichter mit dem Transformer verbunden sind,
- dass die Verbindungen voll in die Transformerboxen eingesteckt sind,
- dass die Steckdose Strom hat (versichern Sie sich, dass alle Schalter, die die Stromzufuhr regeln, auf „AN“ stehen).

Entsorgungshinweis

Dieses Elektro- bzw. Elektronikgerät darf am Ende seiner Lebensdauer nicht im Hausmüll entsorgt werden. Zur Rückgabe stehen in Ihrer Nähe kostenfreie Sammelstellen für Elektroaltgeräte sowie ggf. weitere Annahmestellen für die Wiederverwendung der Geräte zur Verfügung. Die Adressen erhalten Sie von Ihrer Stadt- bzw. Kommunalverwaltung. Sofern das alte Elektro- bzw. Elektronikgerät personenbezogene Daten enthält, sind Sie selbst für deren Löschung verantwortlich, bevor Sie es zurückgeben. Sofern dies ohne Zerstörung des alten Elektro- oder Elektronikgerätes möglich ist, entnehmen Sie bitte alte Batterien oder Akkus sowie Altlampen, bevor Sie es zur Entsorgung zurückgeben, und führen diese einer separaten Sammlung zu.



Bedeutung des Symbols „durchgestrichene Mülltonne“

Das auf den Elektro- und Elektronikgeräten regelmäßig abgebildete Symbol einer durchgestrichenen Mülltonne weist darauf hin, dass das jeweilige Gerät am Ende seiner Lebensdauer getrennt vom unsortierten Siedlungsabfall zu erfassen ist.

Sport-Thieme Fairy Light Canopy

Thank you for choosing this product!

Please read the following notes carefully before use so you can enjoy this product safely and keep these instructions for future reference. If you have any questions, our team is here for you.



Warning

- Safety extra low/voltage transformer for Indoor use only. Must not be exposed to the weather
- Please read these instructions and retain for future reference to ensure the safe and satisfactory operation of the light set

Safety information

- Remove set from box before connecting to power supply.
- Use only with the supplied transformer. Light set is safe for outdoor use however transformer must remain indoors or undercover at all times.
- Disconnect from mains when not in use.
- Do not expose to direct heat, flames or submerge in water. Bulb should not be in contact with combustible materials or materials likely to melt.
- Avoid damage to and rough handling of the wire insulation cable, controller (if set is sold with controller) and bulbs.
- Do not connect this set electrically to any other set. Do not use if wire insulation cable is cut, frayed or damaged or if there are any loose connections of exposed wires.
- Take care that the cable is not damaged if being passed through a doorway or window, especially if the door or window frame is metal.
- LED bulbs cannot be replaced. Do not attempt to remove bulbs.

Controller action

1. Combination
2. In waves
3. Sequential
4. Slo-Glo
5. Chasing/Flash
6. Slow fade
7. Twinkle/Flash
8. Steady on

Trouble Shooting

If lights do not work:

- Make sure lights are connected to the transformer.
- Make sure that the connectors are fully inserted into the transformer box.
- Make sure that the transformer is plugged into a 230V AC outlet.
- Make sure that the outlet has power (make sure any switch that controls the outlet is in the on position).

Notes on Disposal

This electrical or electronic device must not be disposed of in household waste at the end of its service life. Free collection points for waste electrical equipment, as well as additional acceptance points for the reuse of devices, may be available in your area. You can obtain the addresses from your local or municipal administration. If the old electrical or electronic device contains personal data, you are responsible for deleting it before returning the device. If it is possible without destroying the old electrical or electronic device, please remove old batteries, rechargeable batteries, or lamps before disposing of the device and place them in a separate collection.



Meaning of the 'Crossed-Out Wheelie Bin' Symbol

The symbol of a crossed-out wheelie bin, which is regularly displayed on electrical and electronic devices, indicates that the respective device must be collected separately from unsorted municipal waste at the end of its service life.