

Anleitung

19030100

Pedalo® Swing Board

Holz-Hoerz GmbH

Dottinger Str. 71
D-72525 Münsingen

Tel. +49 (0) 7381 - 9357 0

Fax +49 (0) 7381 - 9357 40

info@pedalo.de

www.pedalo.de

Anleitung bitte vor der Benutzung
(oder vor dem Zusammenbau) des Gerätes
komplett lesen und aufbewahren



Allgemeine Informationen und Warnhinweise:

Achtung! Das Gerät ist mit Vorsicht zu verwenden, da es große Geschicklichkeit verlangt, damit Unfälle des Benutzers oder Dritte durch Sturz oder Zusammenstoß vermieden werden. Im Zweifelsfall zunächst das Gerät nur mit Hilfestellung und/oder geeigneter Schutzausrüstung benutzen. Bei der Verwendung durch Kinder wird die Beaufsichtigung durch Erwachsene empfohlen.

Achtung! Das Pedalo-Swing Board immer nur innerhalb der Kufen betreten, ansonsten könnte das Swing Board plötzlich kippen.

Achtung! Verpackungen sind nicht Bestandteil der Artikel und müssen vor dem Einsatz entsorgt werden. Plastiktüten und Plastikfolien gehören nicht in die Hände von Babys und Kleinkindern - Erstickungsgefahr!

Achtung! Benutzen Sie das Gerät ausschließlich für die in dieser Bedienungsanleitung beschriebenen Verwendungszwecke. Auch wenn es sich unter anderem um ein Spielgerät für Kinder handelt, muss der Zusammenbau immer von einem Erwachsenen durchgeführt oder beaufsichtigt werden.

Achtung! Das Gerät nur auf ebenem geradem Untergrund aufstellen. Bei empfindlichen Fußböden eventuell Matte unterlegen.

Nach längerem oder häufigem Gebrauch sollten Sie alle Schrauben kontrollieren und gegebenenfalls nachziehen. Verschlissene Teile umgehend mit Original Ersatzteilen erneuern.


Das Produkt ist aus natürlichem Birken- oder Buchenholz gefertigt. Abweichungen in Farbe, Struktur, Maserung oder kleine Asteschlüsse zeugen von der Echtheit und sind nicht qualitätsmindernd.

Wartung und Pflege:

Kann mit einem feuchten Tuch abgewischt werden. Keine lösemittelhaltigen, säurehaltigen oder scheuernde Reiniger verwenden. Gerät vor Nässe schützen.

Das Gerät ist für eine Benutzung ab einem Alter von 6 Jahren bestimmt

Die maximale Belastbarkeit beträgt 120 kg



Montage der Kufen:

Die Kufen je zwei Querlochmutterbolzen (M6) einsetzen. Der Schlitz der Bolzen muss zur Bohrung an der Kante zeigen.

Die Kufen mit je 2 Senkkopfschrauben (M6 x 30 mm) am Standbrett festschrauben.

Über den Abstand der Kufen kann das Schwingverhalten des Pedalo-Swing Boards verändert werden.

Kleiner Kufenabstand = Höher belastbar und hart

Großer Kufenabstand = geringer belastbar und weich

Der Innensechskantschlüssel kann auf der Brettunterseite unter dem Gummigurtband immer griffbereit aufbewahrt werden.

Anleitung

19030100

Pedalo® Swing Board

Holz-Hoerz GmbH
Dottinger Str. 71
D-72525 Münsingen

Tel. +49 (0) 7381 - 9357 0
Fax +49 (0) 7381 - 9357 40

info@pedalo.de
www.pedalo.de

Before using the device for the first time
(or before starting with assembly),
please **read instruction completely** and keep it.



Important information and warning hints:

Warning! The device is to be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user or third parties. In case of doubt first use the device only with assistance and/or appropriate protective equipment. When used by children the supervision by an adult is recommended.

Warning! Only step on the Pedalo-Swing Board inside the runners, otherwise the Swing Board could suddenly tip over.

Warning! The packing is not part of the product and have to be disposed.

Keep plastic bags and films out of the reach of babies and young children – **RISK OF SUFFOCATION!**

Warning! The device is only to be used for the purposes described in this user manual.

Even if it is, among other things, a plaything for children, the assembly must always be carried out or supervised by an adult.

Warning! Only use device on level ground with even and firm surfaces. On sensible grounds use an anti-slip mat under it if necessary.

After longer or frequent use, check that the screws are tight and retighten if necessary.

Defective and worn parts should be replaced by original replacement parts immediately.

The product is made of natural birch or beech wood. Differences in color, structure, grain, small included knots or scars, prove the genuineness of the material and therefore show no reduction in quality.


Maintenance and cleaning:

Can be wiped off with a damp cloth. Do not use any solvent-based, acidic or abrasive detergents.

Protect item from damp and wet.

This device is meant for using from persons at the age of 6 up.

Maximum weight capacity 120 kg



Assembly of the skids:

Insert two cross hole nuts (M6) each in the runners. The slot of the bolts must face the hole at the edge. Screw the runners to the stand board using 2 countersunk screws (M6 x 30 mm) each. The distance between the runners can be used to change the vibration behaviour of the Pedalo-Swing Board.

Small skid spacing = higher load capacity and hardness

Large runner spacing = less loadable and soft

The hexagon socket wrench can always be stored on the underside of the board under the rubber strap, ready to hand.