

# Roller activity guide

Art.Nr. 2642909

## WARNING

“Assembled by an adult.”

“This item is not a toy and has to be used under the surveillance of an adult.”


### ● Assemble:




Step1




Step2




Step3



Step4



Step5



Done!

### ● Age:4yrs+

### ● Bearable weight: 45kgs

### ● Caution:

1. **DO NOT press on the top of roller or any other way to crush it.**
2. **Please use this item with caution since it requires skill to avoid falls or collisions causing injury to the user or third parties.**

### ● Usage

Get inside the roller in a crawling position and use hands to move forward or backward.

### ● Place

1. Use the roller in a flat ground such as park, backyard and indoor gym where there are no obstacles, stairs, inclines and gap.
2. DO NOT use the roller in a wet place or any other type of liquid on the ground. That might cause the instability of movement and injury.

### ● Maintenance

1. Simply use wet mat to wipe it up. No detergent is needed.
2. Please keep in a dry and clean place. Avoid direct sunlight.