
Prod. code: 115 9501



**Sport-Thieme GmbH** 38367 Grasleben/Germany Tel: +49 (0)53 57/18181 Fax: +49 (0)53 57/181 90

# Assembly instructions for the basketball training unit

Thank you very much for choosing a **Sport-Thieme** product. Please read the instructions fully before you assemble the equipment so you can enjoy the product and its guaranteed safety:



## Included:

Pos. Description

- 1 2 x bracket
- 2 cross member
- 3 basketball backboard 900 x 600 mm
- 4 basketball hoop with net
- 5 fixings

## 1. General

The Sport-Thieme training unit is a complete basketball unit designed for wall mounting. It is constructed for its intended use and should be used accordingly. Hanging from the basketball hoop overloads the unit and is strictly prohibited.


Basketball training unit

Prod. code: 115 950



**Sport-Thieme GmbH** 38367 Grasleben / Germany Tel: +49 (0)53 57/181 81 Fax: +49 (0)53 57/181 90

## 2. Assembly instructions



### III. 1 Backboard drilling holes diagram

Mount the brackets to the wall at the desired height with a distance of 700 mm between the holes. (Competition height: distance between the upper edge of the hoop and the floor is 3050 mm).

Use the wall plugs and screws included.

- Drill through the backboard following the 'drilling holes diagram' in III. 1
- Bolt the backboard and the brackets together (M10x70)
- The cross member is secured by the lower hex bolts.
- Firmly bolt the hoop to the backboard and the cross member's counter plate (M10x50)

Caution: Do not overload or climb the unit!

Make sure that players do not hang from the hoop!

In the case of new installations, ball throwing training equipment (free space behind the board less 1.65 m) should not be positioned opposite to each other to avoid game situations. Load bearing specifications compliant with DIN 18032 and DIN EN 12346 must be observed.

Instructions:

Carry out a visual check at regular intervals.

Due to our continuous quality control of the products, technical changes may occur which may lead to slight deviations in the instructions. At regular intervals, check that the screw connections are tight. Check the equipment for possible damage and replace worn-out parts. Check the condition of wooden elements as chipping and other signs of wear can result from use. Have the unit serviced yearly by an expert.

We are happy to answer any questions you may have.

Your Sport-Thieme Team