

Assembly instructions for tensioning and attachment cables Kangaroo Trampoline



Tensioning cable, approx. 9 mm Ø with spiral hooks on the ends. Assemble in a zig-zag pattern, as shown in illustration 1. Start on the two short sides. Continue along both long sides, making sure that you always attach the middle tensioning cable first and ensuring even tensioning throughout.

Important: ensure that the openings of the spiral hooks face down towards the floor. Note: always tighten the tensioning cables from left to right! Total number of tensioning cables: 10





Attachment cable for the cover, approx. 4 mm Ø, with loops on the ends. Assemble as shown in illustration 2 (picture shows the cover folded back and the white line is the cable). Illustration 3 shows the original attachment cable when the cover is half folded back. Total number of attachment cables: 10

